



Mounting diagram for VARISIL type HE option IF surge arresters

Parts supplied

- ① Surge arrester element with integrated fault indicator (x1)
- ② HM16 nut (x1)
- ③ WZ16 spring washer (x1)

- ④ M16 flat washer (x1)
- ⑤ Line terminal clamp (x1)
- ⑥ WZ12 spring washer (x1)
- ⑦ HM12-35 screw (x1)

